


2001 OWNER'S MANUAL



Note: Your fork's appearance may vary from the illustrations/photos in this manual.

^{*} Denotes updated information since the printed version that came with your fork.

Congratulations! You have the best in suspension components on your bicycle! This manual contains important information about the safe operation and maintenance of your fork. To insure that your RockShox fork performs properly, we recommend that you have your fork installed by a qualified bicycle mechanic. We also urge you to follow our recommendations to help make your bicycling experience more enjoyable and trouble-free.

IMPORTANT

Consumer Safety Information

- 1. Before riding the bicycle, be sure the brakes are properly installed and adjusted. If the brakes do not work properly, the rider could suffer serious and/or fatal injuries.
- 2. If the fork ever loses oil or if it makes sounds of excessive topping out, stop riding the bicycle immediately and have the fork inspected by a dealer or call RockShox. Continuing to ride with the shock in these conditions could result in loss of control of the bicycle with possible serious and/or fatal injuries.
- Always use genuine RockShox parts. Use of aftermarket replacement parts voids the warranty and could cause structural failure to the shock. Structural failure could result in loss of control of the bicycle with possible serious and/or fatal injuries.
- 4. Use extreme caution not to tilt the bicycle to either side when mounting the bicycle to a carrier by the fork drop-outs (front wheel removed). The fork legs may suffer structural damage if the bicycle is tilted while the drop-outs are in the carrier. Make sure the fork is securely fastened down with a quick release. Make sure the rear wheel is fastened down when using ANY bike carrier that secures the fork's drop-outs. Not securing the rear can allow the bike's mass to side-load the drop-outs, causing them to break or crack. If the bicycle tilts or falls out of its carrier, do not ride the bicycle until the fork is properly examined for possible damage. Return the fork to your dealer for inspection or call RockShox if there is any question of possible damage (See the International Distributor List). A fork leg or drop-out failure could result in loss of control of the bicycle with possible serious and/or fatal injuries.
- 5. Only mount cantilever-type brakes to the existing brake posts. Forks with hangerless style braces are only designed for 'V'- style or hydraulic cantilever brakes. Do not use any cantilever brake other than those intended by the brake manufacturer to work with a hangerless brace. Do not route the front brake cable and/or cable housing through the stem or any other mounts or cable stops. Do not use a front brake cable leverage device mounted to the brace.

ROCKSHOX FORKS ARE DESIGNED FOR COMPETITIVE OFF-ROAD RIDING AND DO NOT COME WITH THE PROPER REFLECTORS FOR ON-ROAD USE. YOUR DEALER SHOULD INSTALL PROPER REFLECTORS TO MEET THE CONSUMER PRODUCT SAFETY COMMISSION'S (CPSC) REQUIREMENTS FOR BICYCLE STANDARDS IF THE FORK IS GOING TO BE USED ON PUBLIC ROADS AT ANY TIME.

INSTALLATION

It is extremely important that your RockShox fork is installed correctly by a qualified bicycle mechanic. Improperly installed forks are extremely dangerous and can result in severe and/or fatal injuries.

1. Remove the existing fork from the bicycle and the crown race from the fork. Measure the length of the fork steerer tube against the length of the RockShox steerer tube. The RockShox steerer tube may need cutting to the proper length. Make sure there is sufficient length to clamp the stem (refer to the stem manufacturer's instructions).

A WARNING

DO NOT ADD THREADS TO ROCKSHOX THREADLESS STEERERS. THE STEERER TUBE CROWN ASSEMBLY IS A ONE-TIME PRESS FIT. REPLACEMENT OF THE ASSEMBLY MUST BE DONE TO CHANGE THE LENGTH, DIAMETER OR HEADSET TYPE (THREADED OR THREADLESS).

DO NOT REMOVE OR REPLACE THE STEERER TUBE. THIS COULD RESULT IN THE LOSS OF CONTROL OF THE BICYCLE WITH POSSIBLE SERIOUS AND/OR FATAL INJURIES.

- 2. Install the headset crown race (26.4mm for 1" steerers, 29.9mm for 1 1/8" steerers) firmly against the top of the fork crown. Install the fork assembly on the bike. Adjust the headset until you feel no play or drag.
- 3. Install the brakes according to the manufacturer's instructions and adjust brake pads properly. Use the fork only with V-type or hydraulic cantilever brakes mounted to the existing brake posts or disc style brakes mounted through the provided mounting holes. Do not use any cantilever brake other than those intended by the brake manufacturer to work with a hangerless brace.
- 4. Adjust the front wheel quick release to clear the dropout's counter bore. The quick release nut must be tightened after the wheel is properly seated into the dropout's counter bore. Make sure four or more threads are engaged in the quick release nut when it is closed. Orient the quick release lever in front of and parallel to the lower tube in the locked position.
- 5. Keep in mind tire clearance as you choose tires. Maximum size is 2.6" wide or 347 mm radius installed. Be sure to check this radius whenever you change tires. To do this, remove the air and compress the fork completely to make sure at least 5mm of clearance exists between the top of the tire and the bottom of the crown. Exceeding maximum tire size will cause the tire to jam against the crown when the fork is fully compressed.

PERFORMANCE TUNING

RockShox Psylo forks can be tuned for your particular weight, riding style, and terrain.

Setting Sag

Psylo forks are designed to sag when you are sitting on your bike. Sag is the compression of the fork caused by the rider's weight. Proper sag allows the front wheel to follow the contour of the terrain as you ride. Sag is adjusted by turning the top cap preload adjuster. Turning the adjuster clockwise increases spring preload (i.e. stiffening the spring) decreasing sag. Turning the adjuster counter clockwise decreases spring preload which increases sag.

Fork Travel	Sag	
80 mm	13-20 mm	
100 mm	18-25 mm	
125 mm	20-31 mm	

To measure sag, install a zip tie on the upper tube of the fork flush against the XXX seal. Sit on the bike with normal riding apparel. Step off the bike, and measure the distance between the XXX seal and the zip tie. This is your sag. If you're unable to achieve optimum sag by turning the preload adjuster, you may need to change the fork's spring rate.

Changing the Spring Rate

Spring rate is the amount of force needed to compress a spring one inch. Exchanging your Psylo fork's coil spring for a spring of a higher or lower rate will alter the overall feel of your fork. Higher spring rates make the fork feel more "stiff", while lower spring rates make the fork more "supple". Contact your local RockShox dealer to order replacement springs.

Vari-Adjust All Travel (Figs. 1-3)

Psylo forks can can be adjusted for 80, 100, or 125 mm of travel (or anywhere in between!). To determine the travel on your fork, measure the amount of exposed upper tube (from the bottom of crown to the XXX dust wiper). Compare this measurement to the chart below)

Fork Travel	XXX Seal to Crown
80 mm	100 mm
100 mm	120 mm
125 mm	145mm

CHANGING TRAVEL

- 1. Using a 24mm socket remove the top cap.
- 2. Remove the coil spring.
- 3. Insert a long, flat blade screwdriver into the upper tube. The screwdriver will engage the Vari-Adjust plunger at the bottom of the upper tube.
- 4. From full counterclockwise (80mm travel), 43 turns clockwise are required to achieve 125mm travel. Use the chart below as a guide when adjusting travel.

Fork Travel	Turns from 80mm Travel
90 mm	10 Turns
100 mm	20 Turns
110 mm	30 Turns
125 mm	43 Turns

- 5. Re-install spring and top cap. Torque top cap to 40 in-lb.
- 6. To maximize available travel, it may be necessary to change spring rate. Be sure to check your sag following any change in travel.

External Rebound Adjustment

To change the rebound damping on your Psylo, locate the adjuster knob on the lower right leg. A clockwise adjustment will increase the rebound damping; a counterclockwise adjustment will decrease the rebound damping. Small changes in knob position will make large changes on the trail. Start in the middle, and increase or decrease as necessary.

Climb-It Control

To change the compression damping adjustment on your Psylo, locate the red adjuster knob on top of the right leg. A clockwise adjustment will increase the compression damping. Turning the adjuster completely clockwise will provide "On-The-Fly Lockout" to minimize movement while sprinting or climbing. Incorporated into the Lockout system is a big hit blow-off feature, allowing for fork movement in the event of an unsuspected change in terrain.

MAINTENANCE

To maintain the high performance, safety, and long life of your fork, periodic maintenance is required. If you ride in extreme conditions, maintenance should be performed more frequently.

Before Every Ride

Check the other components on your bicycle in accordance with the manuals supplied by the manufacturer to make sure they are in working order.

After Every Ride

Clean and dry the exterior of your fork. Avoid directing water pressure at the upper tube/XXX seal junction.

Every 25 hours of Riding (Fig. 4)

- Using a small blade screwdriver, carefully push the XXX seal up from the lower tubes. Saturate the foam wiper with RockShox RedRum*. Refit wiper in lower tube.

 Note: To prevent scratching the upper tubes, cover the screwdriver tip with a soft cloth. Carefully lift the foam lubrication ring. Ensure that the foam ring is clean and free of debris.
- Check top cap assemblies, brake post bolts, and shaft bolts for proper torque.

Torque Tightening Values

Top Caps	40	in-lb
Brake Posts	80	in-lb
Shaft Bolts	50	in-lb

Every 50 Hours of Riding

Note: Service on your Psylo can be performed with it still installed on your bicycle. You will need to disconnect the front brake cable and remove the wheel.

Tools required

• 5mm Hex Wrench
• Plastic Face Mallet
• Safety Glasses
• Internal Snap Ring Pliers
• Small Flat Blade Screwdriver
• 5mm Hex Wrench
• 24mm 6-point Socket
• RockShox 5 wt. 0il
• RockShox Judy Butter
• RockShox RedRum

REMOVE SPRING STACK (FIGS. 1-2,4)

- 1. Using a 24mm socket remove the top cap from the left leg.
- 2. Remove the coil spring from the left leg.
- 3. Using a small blade screwdriver, carefully push the XXX seal (gray) up from the lower tubes.

Note: To prevent scratching the upper tubes, cover the screwdriver tip with a soft cloth. Carefully lift the foam lubrication ring. Ensure that the foam ring is clean and free of debris. Leave each on upper tube.

REMOVE LOWER TUBE ASSEMBLY (Fig. 5)

- 4. Gently pull downward to remove rebound adjuster knob.
- 5. Loosen shaft bolts 5 turns and tap firmly with a plastic faced mallet to separate the shafts from the lower tubes.
- 6. Keep a bucket nearby to catch oil. Inspect the condition of removed oil. If the oil is opaque and/or milky (water contamination), the lower tube assembly should be cleaned.
- 7. Remove shaft bolts.
- 8. Carefully slide lower tube assembly off of upper tubes.











Fig. 3 Fig. 4 Fig. 5

CLEAN LOWER TUBE ASSEMBLY

9. Use a biodegradable solvent (Simple Green, Pedro's, or equivalent) and a 12" long, 1 1/4" diameter soft bristle bottle brush to clean the lower tube internals. Dry thoroughly.

REMOVE VARI-ADJUST PLUNGER (FIG. 6)

- 10. Using internal snap ring pliers, remove the retaining ring from the bottom of the upper tube.
- 11. Slide the Vari-Adjust plunger assembly (left side, rider's perspective) out of the upper tube.
- 12. Clean plunger thoroughly.

INSTALL VARI-ADJUST PLUNGER SHAFT

- 13. Install plunger shaft assembly (left leg, rider's perspective) through the bottom of the upper tube.
- 14. Re-install the retaining ring in the upper tube.
- 15 Grease the entire outside diameter of the coil spring with a thin coat of Judy butter.
- 16. Install coil spring and top cap.
- 17. Torque top cap to 40 in-lbs.

INSTALL LOWER TUBE ASSEMBLY

- 18. Slide cleaned XXX seal and foam filter onto upper tubes.
- 19. Carefully slide the lower tube assembly onto the upper tubes until just before the lower bushing engages with the upper tube.

REFILL FLUIDS (FIGS. 7-9)

- 20. With the fork inverted, pour 10 cc 5 wt., oil through the right (rider's perspective) lower shaft bolt hole and 20 cc 5 wt., oil through the left lower shaft bolt hole.
- 21. Slide the lower legs onto the upper tube until they engage with the damper and neutral shafts.
- 22. Install the shaft bolts (hollow bolt on the right side). Torque to 50 in-lbs.
- 23. Install damper adjuster knob
- 24. Install foam ring and XXX seal, pressing the XXX seal flush with the lower leg assembly. A small cable tie inserted between the upper tube and the seal will help eliminate air build-up behind the seal on installation. Remove the cable tie following seal installation.
- 25. Reconnect and adjust front brake cable according to manufacturer's instructions.

PURE DAMPING SYSTEM

Your fork uses a Pure Damping System. With the red Climb-It control lever turned completely clockwise, only a minimal amount of fork movement should be felt. While standing astride the bicycle, press down on the handlebars quickly. A maximum of 6 mm fork movement should be obtainable. Remember, your fork has a blow-off feature for big hits. Some riders may be able to activate the blow-off and achieve more than 6 mm of travel.

When checking the lockout, light to medium pressure on the handlebars best simulates real world riding conditions.

To maintain Lockout control and damping quality, the Pure Damping system should be rebuilt once a year. Only a qualified bicycle mechanic with proper tools should perform a rebuild of the Pure Damping System.

For more detailed service information, contact your local RockShox dealer or visit www.rockshox.com.



Fig. 6



Fig. 7



Fig. 8



Fig. 9

WARRANTY

RockShox, Inc. warrants its products for a period of one year from original date of purchase to be free from defects in materials or workmanship. Any RockShox product that is returned to the factory and is found by RockShox to be defective in materials or workmanship will be repaired or replaced at the option of RockShox, Inc. This warranty is the sole and exclusive remedy. RockShox shall not be held liable for any indirect, special, or consequential damages.

The warranty does not apply to products which have not been properly installed and adjusted according to RockShox installation instructions. The warranty does not cover any product that has been subject to misuse or whose serial number has been altered, defaced or removed. This warranty does not cover paint damage or modifications to the product. Proof of purchase is required.

Warranty Repair

If for any reason it should be necessary to have warranty work done, return the product to the place of purchase. In the USA, Dealers should call for a Return Authorization number (RA#) prior to returning product.

Products returned for inspection must be sent freight prepaid and with proof of purchase to:

RockShox, Inc. 1610 Garden of the Gods Colorado Springs, CO 80907

For more technical information, visit our website at www.rockshox.com. For toll-free technical support in the USA, call 1.800.677.7177. Customers in countries other than the USA should contact their local dealer or distributor.

International Distributor List

Argentina

Broni S.A.
Phone: 54 11 4292 3000
FAX: 54 11 4292 4453
J.J. PASO 1260, (1832) LOMAS DE ZAMORA,
BUENOS AIRES

Australia

Steve Cramer Products
Phone: 61 3 9587 1466
FAX: 61 3 9587 2018
39 INDUSTRIAL DRIVE BRAESIDE, VICTORIA 3192

Austria

Barisitz-Austria
Phone: 43 512 39 22 87
FAX: 43 512 39 45 19

BERNHARD-HOEFELSTRASSE 14, A-6020, INNSBRUCK

Belgium

Vertex Cycle Systems BV Phone: 31 23 57 18184 FAX: 31 23 57 18606

FLEMINGSTRAAT 100A, 2041 VL ZANDVOORT

HOLLAND

Canada

Bell Sports Canada Phone: 403 273 1427 (Calgary) FAX: 403 248 1221 BAY 147, 2760 45TH AVE SE CALGARY, ALBERTA T2B 3M1

Chile

Bicicletas Belda Limitada Phone: 56 32 881799 FAX: 56 32 978799 14 NORTE 1001 VINA DEL MAR

Colombia

Disandina Ltda. Phone: 574-288-8322 FAX: 574-288-6211

CIUDADELA INDUSTRIAL, SIERRA MORENA BODEGA No. 207, CRA. 43 A No. 61 SIR 152, SABANETA Costa Rica

Inversiones Y Sistemes Garvi Phone: 506 296 3383 FAX: 506 289 7013 P.O. BOX 4805-1000, SAN JOSE

Czech Republic

Vanek Praha Phone: 42 0 312 698 1889 FAX: 42 0 312 698 025 CERRENY UJEZD 185, UNHOST, 27351

Denmark Duell A/S

Phone: 45 86 36 7800 FAX: 45 86 36 7377

MOLLERUPVEJ 3, TAASTRUP, 8410 RONDE

Ecuador

Bici Sport
Phone 5932 248737
FAX: 5932 253691

AV DE DICIEMBRE 6327, ENTRE LOUVRE Y TOMAS DE,

BERLANGA.LOCAL #3, QUITO

Estonia

Hawaii Express Phone: 372 6 398 508 FAX: 372 6 398 566

REGATI 1, 5K-102, TALLINN, 11911, Estonia

Or

Estonian Unidream Phone: 372 636 7470 Fax: 372 636 7470 Paavli 2A, Tallinn EE0004, Estonia

Finland

Mr. Cool OY Phone: 358 9 3250817 FAX: 358 9 3250609

LINNAVUORENTIE 28, HELSINKI, 00950

France

Royal Velo France Phone: 33 325 433 730 Fax: 33 325 43 95 95 4 RUE DES AZALEES, P.A. SUD-CHAMPANGE ST THIBAULT, 10800

Germany

Sport Import GmbH Phone: 49 44 05 9280 0 FAX: 49 44 05 9280 49 INDUSTRIESTRASSE 41 B, EDEWECHT, 26188

Greece

Gatsoulis Stefanos Imports Phone: 30 12512 779 FAX: 30 12533 960 8 THESSALONIKIS STREET, NEW FILADELFIA, ATHENS, T.T. 14342

Guatemala

BYS Importaciones S.A. Phone: 502 366 7709 FAX: 502 363 3918 18 CALLE 7-48, ZONA 10, GUATEMALA

Holland

Vertex Cycle Systems BV Phone: 31 23 57 18184 FAX: 31 23 57 18606 FLEMINGSTRAAT 100A, 2041 VL ZANDVOORT HOLLAND

Hong Kong

Flying Ball Bicycle Company Phone: 852 23813661 FAX: 852 23974406

201 TUNG CHOI ST. G/F, MONGKOK KOWLOON

Hungary

Prokero Ltd Co. Phone 361 331 3184 FAX: 361 331 3184

KALMAN IMRE UTCA 23, BUDAPEST, 1054

Iceland

Orninn Hjol Ltd Phone: 354 588 9892 FAX: 354 588 9896

SKEIFAN 11, P.O. BOX 8036, REYKJAVIK

Ireland

Madison Phone: 44 181 385 3385 Fax: 44 208 345 3443 BUCKINGHAME HOUSE EAST, THE BROADWAY STANMORE, MIDDLESEX HA7 4EA

UNITED KINGDOM

Israel

S.I. Noam Phone: 972 3659 7928 Fax: 972 3659 7928 4 HA'ATZMAUT AVE, BAT-YAM, ISRAEL 59441

Italy

Motorquality

Phone: 39 02 24 951 1 FAX: 39 02 24 951 228

20099 SESTO S. GIOVANNI, (MI) I VIA VENEZIA,

(ANG. VIA CARDUCCI), MILANO

Japan

Yoshigai Corporation Phone: 81 729 88 5461 FAX: 81 729 88 5463

5-19, 1-CHOME, SHIMOROKUMANGI-CHO, HIGASHI-

OSAKA JAPAN 579

Korea

KS Sports

Phone: 822 548 5408 FAX: 822 512 3230

SHIN SEUNG BLDG 4TH FLR, 115-4 NONHYUN-DONG,

KANGNAM-KU, SEOUL

Latvia

Veloserviss Phone: 371 750 1292 Fax: 371 750 1298

1/1 HAPSALAS ST., RIGA, LV-1005

Luxembourg

Vertex Cycle Systems BV Phone: 31 23 57 18184 FAX: 31 23 57 18606

FLEMINGSTRAAT 100A, 2041 VL ZANDVOORT

HOLLAND

Mexico

Tekno Bike

Phone: 52 8 336 5602 FAX: 52 8 338 5663

HUMBERTO LOBO #780, COL. DEL VALLE, GARZA

GARCIA, MEXICO, CP, 66220, Mexico

New Zealand

W.H. Whorrall & Co. Ltd. Phone: 64 9 63 6 06 41 FAX: 64 9 63 6 06 31 43 FELIX ST PENROSE, AUCKLAND NEW ZEALAND

Norway

Hallman Sports Phone: 46 18 56 16 00 FAX: 46 18 50 03 22

HALLNASGATAN 8, S-75228 UPPSALA, SWEDEN

Panama

Distribuidora Rali S.A. Phone: 507 220-3844 FAX: 507 220-5303

VIA ESPANS EDIFICA CARCEP, P.O. BOX 87-0852,

PANAMA 7

Peru

Rojo Sports Phone: 511 447 0838 FAX: 511 447 0838

AV. REPUBLICA DE, PANAMA 6513, LIMA 33

Poland

Giant Polska S.P. Z00 Phone: 48 22 645 14 34 FAX: 48 22 645 14 36 AL NIEPODLEGLOSCI 221-4, 02-087 WARSZAWA

Portugal

Bicimax

Phone: 351 44 553276 FAX: 351 44 553187

APARTADO 34, 2431 MARINHA GRANDE

Russia Sportex

Phone: 7095 288 4524 FAX: 7095 288 6888

KUDRINSKAYA PL., 1,, P.O.BOX 33, MOSCOW,

123242

St. Maarten

Tri-Sport International Phone: 5995 43462 FAX: 5995 43928

8 AIRPORT BOULEVARD, SIMPSON BAY, NAMIBIA

Singapore

Treknology Bikes 3 Phone: 65 466 2673 FAX: 65 466 7610

24 HOLLAND GROVE ROAD, SINGAPORE, 1545

Slovak Republic

Paul Lange Oslany Phone: 42 1 862 5492 344 FAX: 42 1 862 5492 350

MIEROVA 854/37 OSLANY, 97247 SLOVAKIA

Slovenia

Proloco Trade Phone: 386 64 380 200 FAX: 386 64 380 2022

ENOTA KRANJ, BRITOF 96A, 4000 KRANJ

South Africa

Coolheat (SA) (PTY) Ltd. Phone: 27 11 807 5282 FAX: 27 11 807 2998

3 RUARGH STREET, PARK CENTRAL, P O BOX 740,

JOHANNESBURG 2001

Spain

K. Motor Dealer S.L. Phone: 34 9 1 637 70 97 FAX: 34 9 1 637 72 64 PARQUE INDUSTRIAL, EUROPOLIS EDIFICO BRUSELA, BLOQUE 4, NAVE 1, LAS ROZAS (MADRID), N/A,

28230

Sweden

Hallman Sports Phone: 46 18 56 16 00 FAX: 46 18 50 03 22

HALLNASGATAN 8, S-75228 UPPSALA

Switzerland

Cilo Bike Service SA Phone: 41 21 641 63 30 FAX: 41 21 641 63 82

CH. DE L'ORIO 30 A, CASE POSTALE 64, CH- 1032

ROMANEL S. LAUSANNE

Taiwan

Biketech Co. Ltd. Phone: 886 22 694 5806 FAX: 886 22 694 6133

NO. 12 FU TEH ROAD, 266 LANE, 37 ALLEY HSICHIH,

TAIPEI HSIEN, TAIWAN, R.O.C.

Thailand

Probike Co. Ltd. Phone: 662 254 1077 FAX: 662 254 1078

237/2 SARASIN ROAD, LUMPINNE, PATUMWAN,

BANGKOK, 10330

Turkey

FBSAT

Phone: 90 212 514 0525 FAX: 90 212 519 4846

EBSAT EMEK BISIKLET, EBUSSUUD CAD NO.67, 34410

SIRKECI, ISTANBUL, 34410

United Kingdom

Madison Phone: 44 181 385 3385 Fax: 44 208 345 3443

BUCKINGHAME HOUSE EAST, THE BROADWAY

STANMORE, MIDDLESEX HA7 4EA

UNITED KINGDOM

Uruguay

International Sports Phone: 5982 782498 FAX: 5982 622532

AVDA. BRASIL 2567, 11800 MONTEVIDEO

Venezuela

Bike Sports Phone 582 751 9709 FAX: 582 753 5071

CENTRO COMERCIAL IBARRA, PLANTA BAJA, LOCAL 3-A CALLE GARCILAZO, COLINAS DE BELLO, O,

CARACAS