

MAINTENANCE INSTRUCTIONS RCK02

Cleaning

Do not clean with a jet wash (KARCHER and similar). We recommend that you spray grease on the 4 pivots on the Rotor every time you wash or wet the Rotor.

It is VERY IMPORTANT when cleaning the rotor, to make sure no pressurised water touches the crankset and its surrounding area.

Greasing

When cleaning and greasing the chain, we should clean and grease the articulated parts of the Rotor. Under no circumstances should you use oils like 3in1.

After exits with rain or each washing, it is recommended to lubricate the four points of turn of the "pushers" with fat in spray.

The use of oils and fats that are not in spray will not make effect, since the toricas meetings which they have the bearings to also protect itself of the entrance of the water will prevent the entrance of these products.

Overhauls

Points that we recommend to review periodically are:

- If the screw that fixes the left crank to the axle is properly screwed on tightly
- If the fixing nut is screwed on tightly; if this had become loose we recommend to review the regulation since the eccentric could have moved
- Comfort of the right crank: If for whatever reason the right crank took a certain lateral play, we would proceed in the following way:
 1. With the Rotor installed, we will put the screw of assembly "M6" (to block the system, therefore it will be more easy to us to conduct this operation)
 2. With the special Rotor Assembly Key making use of its 3 projections we will tighten (to lefts) the connecting rod closing; with it we will unblock the blocking screw (allen of 5 mm)
 3. To continue tightening the connecting rod closing (to lefts) until the play has been reduced and nevertheless is not as tight as to restrain the good turn of the cranks
 4. Tighten more of (to lefts) a quarter of return (1/4)
 5. Tighten the blocking screw until this screw touches with the connecting rod closing
 6. Loosen the connecting rod closing (turning now to rights) a quarter of return (1/4), thus this is blocked against the screw

!WARNING!

* DO NOT CLEAN WITH JET WASH (Kärcher and the like).

* WE RECOMMEND THAT YOU SPRAY GREASE ON THE ROTOR EVERY TIME YOU WASH OR WET THE ROTOR.

